




Park your Fiat Panda on level ground free of stones and branches. The tent attaches to the raised tailgate with the main entrance directly facing it. Ensure that handbrake is on and that gear lever is in neutral position




Remove tent from bag and group poles together in order to erect main frame. The spaced poles are for the main frame, the poles with rounded black ends for the additional porch canopy.




Erect main frame and place next to rear of car so that the highest horizontal bar is parallel to the raised tailgate. The porch canopy will be erected when the tent is up.




Place tent over frame so that window is on Panda's driver side. Place elasticated opening over Panda's tailgate and fasten to rims of rear wheels with coil springs.



Tie laces to frames in all four corners to ensure that tent is secure. Attach guidelines to top four corners and secure in ground with metal stakes.



Finally, erect two poles for the porch canopy and place through two holes. Attach guidelines at top of poles and secure in ground with metal stakes.



CARE OF YOUR TENT.

- * In order to ensure that your tent remains in excellent condition, please take note of the following:
- * Do not tension the tent canvas excessively and keep the entrances closed before guying.
- * Do not pitch your tent under blossoming trees.
- * Do not pack your tent in a wet state. If this cannot be avoided, unpack it after at least 6-8 hours and dry it thoroughly.
- * Grease frame parts slightly after use. When erecting your tent afterwards, rub them off with a soft cloth.
- * Prevent oil and fat from touching the canvas.
- * Do not wash your car with the awning attached to it.
- * Clean the tent canvas only with pure water
- * Never clean window foils with glass detergents.