


## Set-up Instruction

- Put together frame according to the frame plan — except for the lower upright tubes
- Spread out canvas on frame — then mount the uprights
- Care must be taken to place the uprights in the very corners — the canvas has to fit tightly at the sides
- Tie the tent roof to the corner tubes from inside
- Close the entrance
- Peg tent canvas to the ground by means of skewers
- Place your car at a distance of 10–15 cm from the tent.
- Open the hatchback
- Pull the tunnel over the opened hatchback and hook the ends of the elastic band into the rims of the rear wheels

## This is what you should know

- Select your location on a level ground. Remove stones and branches.
- Place the entrance away from the side mostly exposed to the weather.
- Do not tension the tent canvas excessively and keep the entrances closed before guying.
- Do not pitch your tent under blossoming trees.
- Do not pack your tent in a wet state. If this cannot be avoided, unpack it after at least 6–8 hours and dry it thoroughly.
- Grease frame parts slightly after use. When erecting your tent afterwards, rub them off with a soft cloth.
- Prevent oil and fat from touching the canvas.
- Clean the tent canvas only with pure water
- Never clean window foils with glass detergents.



## Where to send your tent, if it needs repairing?

Please send your cleaned tent to the following address, carriage paid:

Messrs. Aquarian  
Phoenix Buildings  
500 King Street, Longton  
Stoke-on-Trent

Messrs. G. T. S. Camping Ltd.,  
Unit 3, Park Road  
Barnet Trading Est.  
Barnet, Herts.

Please do not forget to describe the defect as detailed as possible. If you like they will be readily sending you a price estimate.

Your tent will in any case be repaired at a favourable price and returned to you cash on delivery, carriage unpaid.

In case of claims please proceed in the same way. You will be quickly informed whether your claim can be acknowledged. In case of justified claims we reserve the choice to either repair the tent or to exchange it for another one.

In this case the tent will of course be returned to you free of charge.

As far as your tent is subject to normal use, you will be granted a guarantee of one year as from the day of delivery. Damages caused to zips are however not covered by this regulation. In addition we cannot be held liable for flaws resulting from improper use or force majeure. Please keep this information and your receipt well.

We hope you will enjoy your holidays in your new GOTTSCHALK tent.